RAINSCAPE PROJECT DESIGN For Homes & Schools

WaterWise Rainscape Rebate Class Tom Franke & Michelle Adlong September 5, 2015





Landscape features that retain rainwater on the property

I.WHAT ARE RAINSCAPES? Rain Garden

A vegetated, depressed landscape area designed to capture and infiltrate and/or filter stormwater runoff from impervious surfaces.





I.WHAT ARE RAINSCAPES? Rain Garden



I.WHAT ARE RAINSCAPES? Elevated Rain Garden/Planter Boxes



- Rain gardens are gravityfed systems
- If drainage area is elevated (rooftops, parking garages)...rain garden can be, too!



I. WHAT ARE RAINSCAPES? Berms, Smiles, and Terraces

Low, curved berms that create shallow infiltration basins to capture and slow stormwater runoff facilitating greater infiltration and improving water quality.






Photo: Pennsylvania Stormwater Management Manual

I.WHAT ARE RAINSCAPES? Vegetated Swale

A broad, shallow channel which reduces the flow velocity and filters stormwater runoff



Photo: COA/Rosewood Park

I.WHAT ARE RAINSCAPES? Porous Concrete

A system comprising a limited capacity load-bearing, durable surface together with an underlying gravel layer that temporarily stores water prior to infiltration into the underlying permeable subgrade.



POROUS CONCRETE



I.WHAT ARE RAINSCAPES? Pervious Pavers

These systems consist of high strength concrete units that are separated by open or stone-filled joints that allow stormwater to infiltrate.




II. Site Selection & Design




II. SITE SELECTION & DESIGN Identify drainage area (water source)

Aim to treat:


- Impervious surfaces
- Concentrated flows
 Avoid drainage areas > 2 Ac.





II. SITE SELECTION & DESIGN Where to place Rainscape?

- Consider topography
 - Gravity-driven flow
- Natural landscaped areas
- Lawns
- Leave buffer around:
 - Basements, foundations
 - Trees
- Before you dig, locate underground utilities!





II. SITE SELECTION & DESIGN Discharge & Bypass

- Predict where it goes
- Avoid:
 - Neighbors outside of natural flowpath
 - Garages, chemical storage,
 "hot spots"
- Use flow spreader if possible
- If discharge is concentrated, aim directly toward roadway or drainage infrastructure





Photo: KXAN 2014


Photo: OutboardMotorOilBlog.com

II. SITE SELECTION & DESIGN Lawn Slope

- Limit to 15% max
- Calculate the slope of your lawn


% slope =
$$\frac{\Delta Height}{\Delta Length} \cdot 100$$


• Example



Graphic: COA Grow Green

II. SITE SELECTION & DESIGN





Source: Oregon State University Extension

II. SITE SELECTION & DESIGN **Ponding Depth: Infiltration Rates**

- Where water ponds, design for 😹 **Drawdown time** \leq 48 hours
- Faster drawdown allows deeper garden
- Test your soil's infiltration rate
 - I. Dig a **12" deep** x 6" diameter hole. Insert a ruler & fill with water.
 - for the water to 2.

dis

Time how lor	ng it takes f
sappear	



Water disappears from 12" deep hole in	Rain Garden Max Depth*	
<12 hours	Verify with second test hole.	
l day	12"	
2 days	6"	
4 days	3"	
>4 days	Minimal	

*These guidelines include a factor of safety of 2

II. SITE SELECTION & DESIGN Ponding Depth: Other factors




- What is your soil type?
 - Clayey: Slower drawdown, shallower garden
 - Sandy: Faster drawdown, deeper garden
- Is there a lot of natural groundwater?
 - YES: Shallower garden with bottom higher than groundwater table
- Are you in the Edwards Aquifer Recharge Zone?
 - YES: Additional rules. Liner req'd for basins; shallow ponding only

II. SITE SELECTION & DESIGN Sizing

- The larger the roof, the larger the rain garden
- **Depth** matters more for **small** rain gardens


Rain Garden Area	Rain Garden Average Depth	Percent Runoff Captured*			
		Small Roof (200 SF)	Medium Roof (500 SF)		
Small Rain Garden (100 SF)	3"	91%	75%		
	6"	97%	89%		
	12"	99 %	95%		
Medium Rain Garden (500 SF)	3"	99 %	97%		
	6"	100%	99%		
	12"	100%	100%		
*Includes rainfall on roof and rainscape. Capture varies based on individual site.					



II. SITE SELECTION & DESIGN Sizing


- The larger the roof, the larger the rain garden
- **Depth** matters more for **small** rain gardens

Rain Garden	Rain Garden Average Depth	Percent Runoff Captured*			
Area		Small Roof (200 SF)	Medium Roof (500 SF)		
Small Rain Garden (100 SF)	3"	91%	75%		
	6"	97%	89%		
	12"	99%	95%		
Medium Rain Garden (500 SF)	3"	99%	97%		
	6"	100%	99 %		
	12"	100%	100%		
*Includes rainfall on roof and rainscape. Capture varies based on individual site.					




II. SITE SELECTION & DESIGN

Vegetated Berm & Swale



Photos: Rosewood Park, Austin, TX










Decompaction of Soils prior to placement of topsoil



Keep Flow Path Clear

Often the addition of topsoil, sod, rock, splash pad, etc. is not considered during design or construction and flows are hindered.

Grass blocking flows

Rocks above flow line blocking flows



ROCK OR GRAVEL REQUIREMENT

Gravel or rock rainscape must not extend over 3 feet in width.







IV. MAINTENANCE

"Another flaw in the human character is that everybody wants to build and nobody wants to do maintenance."

— Kurt Vonnegut, Hocus Pocus



Consider Maintenance During Design

- Select native vegetation whenever possible to minimize long term watering needs once established.
- Crushed granite & other materials with fines should not be used as they can clog the system, preventing proper drainage.
- If pedestrian traffic is expected, provide stepping stones to direct walking.



Green Stormwater Infrastructure – Maintenance Manual



GREEN STORMWATER

Completed 2014

Includes:

- Recommended maintenance schedule
- Checklist of items to inspect/maintain for a variety of stormwater control measures

Direct link: https://www.austintexas.gov/department/stormwater-management



Maintenance

IDEAL CONDITIONS

- No erosion or scouring of soil in garden/berm/swale
- No sediment or debris at inlet or within garden/berm/swale
- Uniform coverage with desired vegetation; no weeds
- Uniform mulch coverage
- No visible compaction, water drains within 2 to 3 days



Erosion/Scouring

Erosion or scouring present; Mulch or topsoil is worn away by water flow






Redistribute/replace mulch to consistent 3 inch depth; Cover extensive scouring with appropriately sized rock (typically 3 inch river rock)



Sediment deposits or debris at the inlet





Remove sediment, leaves, debris, and trash from the inlet

Sediment Buildup

Sediment/debris deposits greater than 3 inches deep in bottom of basin





If sediment deposits in discrete piles or uniformly covers bottom of basin, remove with hand tools.

If vegetation is disturbed, replace with in-kind vegetation.

Refer to Grow Green Native & Adaptive Plant Guide for information on appropriate vegetation.


Drawdown Time - How fast should the rain garden empty after it rains?

The City of Austin recommends a drawdown time goal of no more than 2-3 days.

Why 3 days?

- Odors
- Mosquitos (typically take 4 to 5 days to hatch)
- Could affect health of plantings






V. POSITIVE IMPACTS Benefits beyond water conservation

Hydrologic

- Recharge groundwater
- Increase stream baseflow
- Decrease peak runoff rate

Water Quality

 Treat pollutants at the source through biofiltration



ONE TEXAS CENTER

505 Barton Springs Road

